

Trimless Adjustable

5679, 5680, 5681



GB

Please read the instructions carefully before commencing assembly

Live : Normally Brown / Red
Neutral : Normally Blue / Black
Earth : Normally Green / Yellow

E

Leer atentamente las instrucciones antes de comenzar el montaje

Fase : Normalmente Marrón / Rojo
Neutro : Normalmente Azul / Negro
Tierra : Normalmente Verde / Amarillo

F

Lire attentivement les instructions avant de commencer le montage

Phase : Normalement Brun / Rouge
Neutre : Normalement Bleu / Noir
Terre : Normalement Vert / Jaune

D

Lesen Sie bitte die Anweisungen sorgfältig durch, bevor Sie mit dem Zusammenbauen beginnen

Phase : Normalerweise Braun / Rot
Nulleiter : Normalerweise Blau / Schwarz
Erde : Normalerweise Grün / Gelb


For ceiling use only.
Seulement pour montage au plafond.
Nur für den Deckengebrauch.
Para utilizar sólo en techos.




Not suitable for mounting **in** flammable materials, e.g. wood.
Nicht für das Anbringen **in** flammbaren Material geeignet.
Ne convient pas pour montage **dans** des matériaux inflammables.
No apto para el montaje **dentro** de materiales inflamables.



Not suitable for covering with thermal insulation.
Nicht für die Abdeckung mit Wärmedämmung geeignet.
Ne peut être recouvert de matériaux d'isolation.
No apto para cubiertas con aislamiento térmico.




I




TURN OFF POWER!
COUPEL LE COURANT!
STROM ABSHALTEN!
CORTE LA CORRIENTE!

2

5679 Trimless Adjustable Round





Ø 111mm

5680 Trimless Adjustable Square



111mm

111mm


5681 Trimless Adjustable Twin



215mm

111mm

3




Neutral/Neutre/Neutro/Nulleiter
Blue/Black
Bleu/Noir
Azul/Negro

Earth/Terre/Tierra/Erde
Green/Yellow
Vert/Jaune
Verde/Amarillo


Earth/Terre/Tierra/Erde
Green/Yellow
Vert/Jaune
Verde/Amarillo

Live/Phase/Fase
Brown/Red
Brun/Rouge
Marrón/Rojo
Braun/Rot


4



5



6



7

